




Quick Installation Guide

X1-SPLIT 3.0KW-7.0KW


Installation

Size




Space

Reserve enough space when installing inverter (at least 300mm) for heat dissipation.



X1-SPT 6K/7K



I

Packing List

					Common material
					difference material for X1-SPT 3K/3.6K
					difference material for X1-SPT 6K/7k

III

Mounting Steps

a) Use a marker to mark drilling holes of the bracket on the wall. (X1-SPT 6-7k need 5 holes) Drill holes at marked spots with depth of 65mm.

b) Insert expansion bolt into the hole, use rubber hammer to knock the expansion screw bolt into the wall. The bracket is aligned with the screw uses the inner hexagonal wrench to screw the tapping screw until the expansion bolt "bang" is heard.

c) Hang the buckle on the X1-SPT inverter to the corresponding position of the backplane. Use the inner hexagonal wrench to tighten the inner hexagonal screw on the right side of the inverter.

IV

PV Connection

Step 1. Turn off the DC switch, connect the PV module, prepare a 12 AWG PV cable, and find the PV (+) terminal and PV (-) terminal in the package.

Step 2. Use a wire stripper to strip the 7mm insulation layer of the wire end.

Step 3. The PV connector is divided into 2 parts, to the plug and the fastening head. Pass the cable through the fastening head and the alignment plug. Note that the red and black lines correspond to different pairs of plugs. Finally force the cable into the plug and hear a "click" to indicate that the connection is complete.

Step 4. Tighten the fastening head and into insert the corresponding positive and negative (PV-/PV+) parts of the inverter.

V

Grid and Load Output Connection

Step 1. Prepare a Grid cable (three-core wire) and an Load cable (two-core wire), and then find the European terminal and waterproof cover in the accessory bag.

Step 2: The Grid and Load cables go through the corresponding Grid and Load ports of the waterproof cover. Remove the 12mm insulation layer at the end of the wire. Insert the European-style terminals respectively, and make sure that the stripped ends are inserted into the European-style terminal, and finally use crimping pliers to press tightly.

Step 3. Find the location of the AC interface on the inverter, insert the crimped terminals into the UW10 terminals L1, N, and L2 according to the wire sequence, and use a flat-blade screwdriver to tighten the screws. (Torque: 0.2±0.1N·m) Install the AC waterproof cover, and tighten the screws on the four sides of the waterproof cover with an Allen wrench. Tighten the waterproof fastening head.

Model	X1-SPT-3K	X1-SPT-3.6K	X1-SPT-6K	X1-SPT-7K
Cable (copper)	5.5mm ²	5.5mm ²	8mm ²	8mm ²
Micro-Breaker	40A	40A	50A	50A

Model	X1-SPT-3K	X1-SPT-3.6K	X1-SPT-6K	X1-SPT-7K
Cable (copper)	5.5mm ²	5.5mm ²	8mm ²	8mm ²
Micro-Breaker	20A	20A	30A	30A

VI

Battery Connection

Step 1. Prepare 8 AWG battery power line, find the DC plug (+), DC plug (-) in the accessory bag.

Step 2. Insert the striped cables into the DC plug (-) and DC Plug (+) respectively.

Step 3. Press down on the spring by hand, you can hear a click sound, then push the ends together, and tighten the screw joints.

Step 4. Insert the battery power lines into the corresponding BAT port (+), (-) of the inverter.

Note: BAT port, not PV port!
Note: The positive and negative wires of the battery are not allowed to be reversed!

Notice!
After the BMS communication between the battery and the inverter is finished, the battery will work normally.

VII

Communication Connection

CT connection

X1-SPT 3K/3.6K

X1-SPT 6K/7K

Note: The arrow on the CT must point at the public grid. CT port is at the bottom of the inverter.


BMS connection

Note: The BMS port on the inverter is the communication port for connecting the battery. The communication port on the lithium battery must be consistent with the definition of pins 4, 5, 7, and 8 above.

VIII Communication Connection

COM Communication

External communication equipment controls the inverter:



Inverter communication control external equipment:




COM PIN Definition

1	2	3	4	5	6	7	8
Drycontact_A(in)	Drycontact_B(in)	+13V	485A	485B	GND	Drycontact_A(out)	Drycontact_B(out)


Customers can communicate or control the inverter and external devices through the COM interface. Professional users can use pins 4 and 5 to realize data acquisition and external control functions. The communication protocol is Modbus RTU. For details, please contact Solax. If the user wants to use the inverter dry contact to control external equipment (such as a heat pump), it can be used with Solax's Adapter Box. For details, please refer to the Quick Installation Manual of the Adapter Box. It must be consistent with the definition of pins 4, 5, 7, and 8 above.

X Grounding Connection(mandatory)

Step 1. Prepare a one-core cable (10AWG), and then find the ground terminal in the accessories.




Step 3. Find the ground connection port on the inverter, and screw the ground wire on the inverter with an M5 Allen key.




IX COM Connection Steps


Step 1. Prepare a communication cable, and then find the communication adapter in the accessory bag.




Step 3. Insert the prepared communication cables into the RJ45 terminals in sequence, and then use network cable crimping pliers to press them tightly.




Step 5. Finally, find the corresponding BMS / Meter / CT / COM ports on the inverter and insert the communication cable into the corresponding ports.



Step 2. Insert the communication cable through the communication adapter, and peel off the outer insulation layer of 15mm.




Step 4. Tighten the completed BMS / CT / COM communication line and tighten the waterproof plug.




XI Monitoring Operation

Wireless monitoring accessories connection steps:

Step 1. First find the DONGLE port of the inverter.




DONGLE connection diagram



Step 2. Plug Pocket WiFi into the DONGLE port.

Please check the Pocket WiFi user manual/Pocket LAN user manual /4G user manual for more details.



XII Start the Inverter

After the inverter is checked, then conduct the following steps

1. Make sure that the inverter is fixed on the wall.
2. Ensure that all ground wires are grounded.
3. Confirm that all DC lines and AC lines are connected.
4. Make sure the CT is connected.
5. Make sure the battery is well connected.
6. Turn on the Grid switch and Load switch.
7. Turn on the battery switch.

Start the inverter

- Steps to start the inverter
 - Turn on the AC switch between the X1-SPT and the power grid.
 - (Optional) Remove the locking screw from the DC switch.
 - Turn on the DC switch between the PV string and the X1-SPT if there is any.
 - Turn on the DC switch at the bottom of the X1-SPT.
- When the photovoltaic panel generates enough power, the inverter will start automatically.
- Check the status of the LED screen, the LED is green.
- If the LED is not green, please check the following:
 - All connections are correct.
 - All external disconnect switches are closed.
 - The DC switch of the inverter is set to the "ON" position.
 - All external disconnect switches are closed.
 - The DC switch of the inverter is set to the "ON" position.

XIII Firmware Upgrading

Upgrade steps

Step 1. Please save the "Upgrade" firmware in your U disk, and insert the USB flash drive.

Step 2. Observe the LED indicator light.

Note: The upgrade sequence is: DSP program, battery master control, battery slave control (twice), ARM program.

(X1-SPT 3k/3.6k)		(X1-SPT 6k/7k)	
Upgrade progress	LED indicator	Upgrade progress	LED indicator
0%-33%	Blue flashing, Green off, Red off	33%	Green flashing, Blue off, Red off
33%-66%	Blue on, Green flashing, Red off	33%-66%	Green on, Blue flashing, Red off
66%-99%	Blue on, Green on, Red flashing	66%-99%	Green on, Blue on, Red flashing
Current object upgrade complete	Blue on, Green on, Red on	Current object upgrade complete	Green on, Blue on, Red on
All objects upgrade complete	Blue flashing, Green flashing, Red flashing	All objects upgrade complete	Green flashing, Blue flashing, Red flashing
Upgrade failed	Blue flashing, Green flashing, Red off	Upgrade failed	Green flashing, Blue flashing, Red off
Battery upgrade failed	Blue off, Green flashing, Red flashing	Battery upgrade failed	Green off, Blue flashing, Red flashing

XIV Safety Instructions



Indicates that the product must not be processed with household waste. It must be brought to an electric and electronic waste collection point for recycling and disposal. By ensuring the appropriate disposal of this product you also help in preventing potentially negative consequences for the environment and human health. The recycling of materials helps preserve our natural resources. For further information regarding the recycling of this product, please contact your municipality, local waste disposal centre or the store where the products was purchased.

Please contact us if you have any further confusions

Solax Power Network Technology (Zhejiang) Co., Ltd.
 ADD Lv 9, Lotus Business Center North Building, 333 Lianhua St,
 Xihu District, Hangzhou, Zhejiang Province, CN 310063
 Tel +86 571 56260011
 FAX +86 571 56075753
 EMAIL service@solaxpower.com
 WEB www.solaxpower.com